

APPLICATION FILTER GUIDE



KOMATSU PC 45 R-8 Yanmar F22295->

Image	Description	Ref
	Cab Air Filter Qty Rqd x2 outer	SKL461902
	Cab Air Filter Qty Rqd x2 outer	RA4099
	Cab Air Filter Prefilter	SKL461912
	Cab Air Filter	RC6913
	Air filter Safety	RA2013
	Air filter	RA2012
	Oil Filter	RL3012
	Fuel Filter Pre Filter	RF1118
	Fuel Filter F22295-	RF1011
	Pre Fuel Filter F22295-	RF1030



Hydraulic filter

RH4529