















APPLICATION FILTER GUIDE



TAKEUCHI TB 1140 SERIE 2 Isuzu 4JJ1XYSB01 51440001->

Image	Description	Ref
	Ventilation filter Hydraulic	RA2044
	Cab Air Filter Internal	SKL46208
	Cab Air Filter External	SKL46225
	Air filter Safety	RA2009
	Air filter	RA2008
	Oil Filter	RL3044
	Fuel Filter Secondary	RF1100
	Fuel Filter Primary	RF1092
	Fuel Filter PREF/VORF PPE	SKV407
	Pilot Hydraulic filter	RH4030

		
	Hydraulic filter Suction	HY90317
	Hydraulic filter Return	HY97107
	Filter Kit Engine	FK57242X
	Filter Kit Complete	FK57242