










APPLICATION FILTER GUIDE



BOBCAT TL 470 (X) Perkins 1104D-44TA

Image	Description	Ref
	Cab Air Filter	SKL46653
	Air filter Safety	RA2009
	Air filter	RA2008
	Oil Filter	RT5002
	Fuel Filter	RF1019
	Hydraulic filter	HY9276
	Hydraulic filter Return	HY90646
	Fuel Water Separator Filter	RF1119
	Filter Kit Engine	FK73314X
	Filter Kit Complete	FK73314

		
---	--	--