








# APPLICATION FILTER GUIDE



**BOMAG BW 100 ADM-2W Kubota D722E/B**

Image	Description	Ref
	Ventilation filter	STB5011
	Air filter 2004-	RA2001
	Air filter -2004	RA2018
	Oil Filter	RL3001
	Fuel Filter Pre Filter	RF1002
	Fuel Filter	RF1003
	Hydraulic filter	RH4137