







APPLICATION FILTER GUIDE



CAT 328 D-LCR Cat SWF1->

Image	Description	Ref
	Cab Air Filter Internal	SKL46218
	Cab Air Filter External	RC6008
	Air filter Safety	P532504
	Air filter	RS3506
	Air filter MOT	SBL88079
	Ventilation filter Hydraulic	UCCUCSAB156340
	Ventilation filter HYD +	SBL88035
	Oil Filter	P551807
	Fuel Filter Secondary	RF1072
	Fuel Filter Primary	SN55437

		
	Hydraulic filter PRESSION/DRUCK	SPH94010
	Hydraulic filter Return	PT9556-MPG
	Hydraulic filter Spin On	BT305
	Filter Kit Engine	FK8127X
	Filter Kit Complete	FK8127