












APPLICATION FILTER GUIDE



HITACHI ZX 110 Isuzu BB-4BG1T 2003->

Image	Description	Ref
	Cab Air Filter	RC6002
	Cab Air Filter Pre Filter	PA5662
	Air filter Safety	RA2022
	Air filter	RA2021
	Air filter Safety	RA2096
	Air filter Option	RA2095
	Oil Filter	RL3044
	Fuel Filter	RF1009
	Fuel Filter OPTION PREF/VORF	BF798
	Pilot Hydraulic filter	RH4007

		
	Hydraulic filter FIBRE/FIBER	HY902941
	Hydraulic filter Option	PT9443