















# APPLICATION FILTER GUIDE



### HITACHI ZX 190 W-3 Isuzu AL-4HK1X

Image	Description	Ref
	Cab Air Filter outer	RC6028
	Cab Air Filter Internal	RC6029
	Ventilation filter	RA2044
	Air filter Safety	SL81497
	Air filter	SL81496
	Oil Filter	RL3044
	Fuel Filter	RF1093
	Fuel Filter	RF1092
	Hydraulic filter suction	HY90544
	Trans Hydraulic filter	BT9440

		
	Pilot filter	HY90308
	Hydraulic filter Return	SH60328
	Filter Kit Engine	FK77159X
	Filter Kit Complete	FK77159