
















APPLICATION FILTER GUIDE



TAKEUCHI TL 12 Kubota V3800-CR-TE4B 2014-> 201200002->

Image	Description	Ref
	Cab Air Filter Internal	PA2218
	Cab Air Filter external	SKL46282
	Ventilation filter Engine	SA08618
	Ventilation filter Hydraulic	SBL88008
	Air filter Safety	RA2007
	Air filter	RA2006
	Oil Filter	RL3010
	Fuel Filter Secondary	BF957
	Fuel Filter Primary	RF1009
	Fuel Filter Pre Filter	RF1053

		
	Trans Hydraulic filter	PT8425
	Hydraulic filter Suction	HY90237
	Hydraulic filter Return	HY95332
	Filter Kit Engine	FK57309X
	Filter Kit Complete	FK57309