











# APPLICATION FILTER GUIDE



### SHOVEL ZX 250 ISUZU AH4HK1XYSA6 2006-

Image	Description	Ref
	Cab Air Filter Internal	RC6029
	Cab Air Filter External	RC6028
	Air filter Safety	RA2096
	Air filter	RA2095
	Oil Filter	RL3044
	Fuel Filter H:205MM	RF1093
	Fuel Filter H:143MM Option	RF1100
	Fuel Filter Primary	RF1092
	Pilot Hydraulic filter	RH4007
	Hydraulic filter Return	PT9557

		
	Hydraulic filter Suction	RH4002