










APPLICATION FILTER GUIDE



BOBCAT T 190 Kubota V 2607-DITE3B 5270 11001->

Image	Description	Ref
	Air filter Safety	RA2046
	Air filter	RA2019
	Cab Air Filter heating	SKL46397
	Cab Air Filter Recirculation / Umluft	SC90158
	Oil Filter	RL3032
	Fuel Filter	RF1020
	Hydraulic filter secondary	SH66172
	Hydraulic filter primary	RT5013
	Hydraulic filter inline	HY90791
	Hydraulic filter charge filter later models	HY90632

		
	Filter Kit Engine	FK73271X
	Filter Kit Complete	FK73271