








# APPLICATION FILTER GUIDE



**BOMAG BW 100 ADM-2W Kubota D722E/B**

| Image   | Description               | Ref     |
|---|---------------------------|---------|
|     | Ventilation filter        | STB5011 |
|    | Air filter<br>2004-       | RA2001  |
|    | Air filter<br>-2004       | RA2018  |
|   | Oil Filter                | RL3001  |
|  | Fuel Filter               | RF1003  |
|  | Fuel Filter<br>Pre Filter | RF1002  |
|  | Hydraulic filter          | RH4137  |