








APPLICATION FILTER GUIDE



BOMAG BW 90 AC-2W Kubota D722B

Image	Description	Ref
	Air filter RADIALSEAL	RA2001
	Air filter Option	RA2018
	Oil Filter	RL3001
	Fuel Filter	RF1003
	Fuel Filter Pre Filter	RF1002
	Hydraulic filter Spin On	RT5271
	Hydraulic filter Option Element	RH4137