











APPLICATION FILTER GUIDE



CAT 936 Cat

Image	Description	Ref
	Cab Air Filter	PA2626
	Air filter Safety RADIALSEAL	RS3505
	Air filter RADIALSEAL	RS3504
	Air filter Safety	PA1675
	Air filter Option	PA1634
	Oil Filter	B7600
	Fuel Filter SERIE 45Z1	RF1008
	Fuel Filter SERIE 33Z1	P557440
	Trans Hydraulic filter	SN5057
	Hydraulic filter	PT83

		
---	--	--