














APPLICATION FILTER GUIDE



DOOSAN DX 140 LCR-5 Perkins 1204F-E44TAN 2016 1001->1039

Image	Description	Ref
	Breather hyd filter Engine filter	SA016751
	Breather hyd filter Filter for hydraulic tank	SBL88036
	Piloting hydraulic filter	HY90836
	Hydraulic filter Filter mounted on the suction side	SH60081
	Hydraulic filter Return line filter	HY907741
	Cabin air filter Internal	RC6294
	Cabin air filter External	SKL46634
	Security air filter	P611189
	Primary air filter	P611190
	Diesel oil filter Secondary filter	SK48548
	Diesel oil filter	SK48602

	Primary filter	
	Diesel oil filter PREF/VORF IN LINE	SK48601
	Oil filter	P550920